

# Couplings, Adaptors & Swivels

| PART NO. | DESCRIPTION |
|----------|-------------|
|----------|-------------|

## Nitto Standard Series Adaptors – Steel



|             |                                |
|-------------|--------------------------------|
| <b>20PM</b> | Nitto 20PM 1/4BSP Male Adaptor |
|-------------|--------------------------------|

|             |                                |
|-------------|--------------------------------|
| <b>30PM</b> | Nitto 30PM 3/8BSP Male Adaptor |
|-------------|--------------------------------|

|             |                                |
|-------------|--------------------------------|
| <b>40PM</b> | Nitto 40PM 1/2BSP Male Adaptor |
|-------------|--------------------------------|

|             |                             |
|-------------|-----------------------------|
| <b>20PH</b> | Nitto 20PH 1/4 Barb Adaptor |
|-------------|-----------------------------|

|             |                             |
|-------------|-----------------------------|
| <b>30PH</b> | Nitto 30PH 3/8 Barb Adaptor |
|-------------|-----------------------------|

|             |                             |
|-------------|-----------------------------|
| <b>40PH</b> | Nitto 40PH 1/2 Barb Adaptor |
|-------------|-----------------------------|

|             |                                |
|-------------|--------------------------------|
| <b>20PF</b> | Nitto 20PF 1/4BSP Fem. Adaptor |
|-------------|--------------------------------|

|             |                                |
|-------------|--------------------------------|
| <b>30PF</b> | Nitto 30PF 3/8BSP Fem. Adaptor |
|-------------|--------------------------------|

|             |                                |
|-------------|--------------------------------|
| <b>40PF</b> | Nitto 40PF 1/2bsp Fem. Adaptor |
|-------------|--------------------------------|